




# POWER



# LED




# USB




# MCU


## CH32V103C\_MINI




# XTAL




# BOOT




# PIN



# RST




# DEBUG






### XTAL




### MCU


## CH32V103C\_EVT




### BOOT



### RST




### POWER




### TOUCHKEY



平面按键（大圆盘）




### PIN




### DEBUG





### EEPROM



### TF CARD




### UART




若使用232, 则用跳冒连接3-4、5-6


### LED




### SPI FLASH




### USB




# POWER



# LED




# USB




# MCU


## CH32V103R\_MINI




# XTAL




# BOOT



# RST



# PIN



# DEBUG

